

PARTS
HIGH SPEED TAPE PUNCH SET
(BRPE)





**BULLETIN 1154B** 

PARTS
HIGH SPEED TAPE PUNCH SET
(BRPE)



SKOKIE, ILLINOIS, U. S. A.

#### LIST OF EFFECTIVE PAGES

JULY, 1960

(Supersedes May, 1960 Issue)

Page Number	Change In Effect
A to B	Change 5
C to E	Change 3
1-1 to 1-21	Change 3
2-1 to 2-10	Change 3
3-1	Change 3
3-2 to 3-3	Change 5
3-4 to 3-7	Change 3
3-8 to 3-9	Change 5
3-10	Change 4
3-11	Change 3
3-12 to 3-17	Change 5
4-1 to 4-3	Change 3
5-1	Change 3
5-2 to 5-4	Change 5

The above list indicates the effective pages as of the date of issue. Upon receipt of change pages, insert them numerically and discard any superseded pages.

#### TABLE OF CONTENTS

	Page Numbe
Variable Feature Chart (Units Covered) Photographs	C D,E
SECTION 1 - Tape Punch (BRPE6 and up) and Base (BRPEB6 and up)	
Punch and Toggle Link Mechanism  Main Shaft  142925 Chad Box Assembly  Front Cover	1-2 1-4 1-6 1-8 1-10 1-12 1-14 1-16 1-18 1-20
SECTION 2 - Tape Punch (BRPE1, 2, 3 and 5) and Base (BRPEB2, 3 and 4)	
Base Assembly	2-2 2-3 2-4 2-5 2-6 2-7 2-8 2-9 2-10
SECTION 3 - Motor Units	
LMU3 and LMU15 Synchronous Motor Units	
SECTION 4 - Miscellaneous Reference	
Notes of Explanation	4-2 4-3


SECTION 5 - Numerical Index

	V	ARIATION	us in th	E HIGH :	SPEED TA	APE PUN	CHES			
TAPE PUNCH (BR	PE)	andre de la Colonia de	1 1	2	3	5	6	7	8	9
ASSOCIATED BA	SE (BRPEB)		4	2	3	2	6	Note 1	7	8
ASSOCIATED CC	VER	136127 BRPEC	X	X	Х	У	X		X	X
	FIVE	J DIVI LO	X		X			Х		X
UNIT CODE	SIX	ACC				X				
5.1	SEVEN			X						
	EIGHT						X		X	
STYLE OF	IN-LINE		X	X	X		Х	X	Х	Х
FEED HOLE	ADVANCE	D				X				
TAPE	FULLY PERFOR	RATED	X	X	X	X	Х	X	Х	Х
PERFORATIONS	CHADLESS									
	11/16"		Χ		X			Х		X
WIDTH OF TAPE 7/8"				X		X	X		Χ	
	יין						X		X	
NUMBER OF TIMING	ONE				X		Note 2	Note 2	Note 2	Note 2
CONTACTORS	TWO		X	X		X	NOIE Z	14016 2	14016 2	INDIC 2
MANUAL TAPE FEED OUT		X	X		×	X	X	X	X	
TAPE OUT ALARM				Х		Х		X	X	
MOTOR SWITCH		X	×		×	X		Х	X	
TUBE CONTROLLED		X	X	X	Х			Х		
TRANSISTOR CONTROLLED						X	X		Х	
CARLEC	TAPE PUN	1CH	135084	124347	135683	135186	142886	1707 <i>5</i> 7	142938	142800
CABLES	BASE		124393	124393	136420	124393	142961		142939	143009

Note 1: associated base (LRXB), component of the reperforator transmitter set (refer to 1168B).


Note 2: Magnetic pickup replaced contactors.

		FINISH COLO				
	SMOOTH FINISHES			WRINKLE FINISHES		
Suffix	Color	Bell System Code	Suffix	Color	Bell System Code	
BB	Black Semi-Gloss	34	AA	Black	37	
BA	Black High Gloss					
BK	Gray Green		AB	Gray Green	40	
			AC Light Brown			
			AD	Dark Brown	<b>3</b> 8	
ВН	Light Gray		AF	Federal Gray		
BU	Light Gray Semi-Gloss					
B∨	Federal Gray					
BZ	Charcoal Gray					
BX	Sunland Beige					
Suffix to be applied following the part number.						



HIGH SPEED TAPE PUNCH (BRPE1 THROUGH BRPE5)

CONSISTS OF A REPERFORATOR UNIT (BRPE), MOTOR UNIT (LMU) AND A BASE (BRPEB)




HIGH SPEED TAPE PUNCH (BRPE6 AND UP)


CONSISTS OF A REPERFORATOR UNIT (BRPE), MOTOR UNIT (LMU), BASE (BRPEB) AND A COVER (BRPEC200)

## SECTION 1


TAPE PUNCH (BRPE6 AND UP)
AND BASE (BRPEB6 AND UP)



Part	
Number	Description
1036	Nut (6-40 Hex)
2191	Washer, Lock
2449	Washer, Lock
2669	Washer, Lock
7002	Washer, Flat
70072	Washer, Lock
74805	Screw (10-32 x 3/4 Hex)
82474	Terminal
85020	Screw, Shoulder (10-32)
91683	Nut $(15/32-32 \text{ Hex})$
91684	Nut (15/32-32 King)
93985	Washer, Lock
98726	Screw (3-48 x 1/4 Fil)
111017	Screw (6-40 $\times$ 5/16 Rd)
114466	Connector, Receptacle
114467	Connector, Plug
114589	Mount, Vibration
119337	Plate, Name
124396	Switch Assembly
130361	Nut (1/4-32 Hex)
131098	Terminal
142898	Connector, Plug (24 Pt.)
142899	Connector, Receptacle (24 Pt.)
142915	Bracket, Mounting
142939	Cable Assembly
142950	Bar, Left
142951	Bar, Right
142952	Plate, Mounting
142953	Post
142954	Stud
142955	Bracket, Rear Left
142956	Bracket, Right Rear
142959	Plate
142961	Cable Assembly, Base
142964	Board Assembly, Terminal
142965	Board Assembly, Terminal
142966	Resistor
142970	Post
142971	Strip, Rear
142972	Strip, Front
142985	Cable Assembly, Motor
150966	Insulator
151335	Stud
151346	Screw (6-40 × 3/8 Fil)
151415	Block, Insulating
151626	Terminal
151657	Screw (6-40 x 1/4 Fil)
151723	Screw (10-32 x 3/8 Hex)
151724	Screw (10-32 x 5/8 Hex)
154661	Rectifier
154697	Grommet, Rubber
155752	Sleeve, Insulating
156768	Screw (8–32 x 9/32 Hex)




Part	
Number	Description
2191	Washer, Lock
2669	Washer, Lock
3606	Nut (6-40 Hex)
6745	Screw (10-32 $\times$ 1/2 Hex)
74036	Nut (10-32 Hex)
74712	Spring
80845	Screw (10-32 x 1-13/16 Fil)
119649	Ring, Retaining
124374	Bushing
124375	Plate, Front
124381	Stud
124382	Washer, Flat
135086	Retainer, Tape
135670	Lever, Alarm
139770	Spring
142974	Roller
142975	Brake
142976	Shaft
142977	Reel, Tape
142982	Guide, Tape
143002	Plate, Rear




Part	
Number	
2191	Washer, Lock
3640	Washer, Lock
7002	Washer, Flat
70529	Stiffener
74728	Terminal
82097	Spring, Contact
82547	Insulator
82548	Insulator
84666	Spring, Contact
84705	Spring, Contact
97 <b>2</b> 66	Plate, Clamp
112100	Bushing, Insulating
125011	Washer, Flat
143000	Contact Assembly, Tape Out
143001	Bracket
143003	Stud
143004	Cover, Insulating
151880	Nut (4-40 Hex)
156740	Screw (6 <b>-</b> 40 x 7/32 Hex)





Part	
Number	Description
2191	Washer, Lock
2669	Washer, Lock
3598	Nut (6-40 Hex)
3599	Nut (4-40 Hex)
3606	Nut (6-40 Hex)
3640	Washer, Lock
7002	Washer, Flat
34432	Washer, Flat
41675	Flat
36463	Spring
86774	Screw, Shoulder (6-40)
90361	Washer, Felt
110435	Nut (4-40 Hex)
110743	Washer, Lock
111017	Screw (6-40 $\times$ 5/16 Rd)
112626	Nut (10-32 Hex)
115221	Washer, Felt
119648	Ring, Retaining
119652	Ring, Retaining
124249	Spacer
124258	Screw, Shoulder (4-40)
124282	Spacer (4 40)
124287	Spacer
124300	Spacer
125252	Spring
135247	Oiler, Felt
139991	Post, Spring
142800	Plate, Rear
142811	Stud, Eccentric
142812	Stud, Toggle Arm Spacer
142828	Pawl, Feed
142829	Pin
142834	Bail, Toggle Arm
142923	Post
143006	Lever W/Post
143014	Link W/Hub and Stud
143016	Arm W/Pin, Toggle
143017	Arm, Toggle
143019	Spacer
143020	Spacer
143021	Plate W/Post & Stud
143026	Eccentric
143028	Scale
143045	Link W/Bushings
<b>⇒</b> 143048	Spring
151724	Screw (10-32 x 5/8 Hex)
170752	Plate, Rear
·· -· - <del>-</del>	






Page Number	Description
1159	Screw (4-40 x 3/8 Fil)
1164	Screw (2-56 x 3/16 Fil)
2191	Washer, Lock
2669	Washer, Lock
3598	Nut (6-40 Hex)
3599	Nut (4-40 Hex)
3640	Washer, Lock
7002	Washer, Flat
42823	Washer, Flat
82726	Spring
93117	Washer, Lock
110434	Screw (4-40 × 3/16 Fil)
110435	Nut (4-40 Hex)
110743	Washer, Lock
111410	Washer, Flat
119651 124244	Ring, Retaining Washer, Felt
124257	Arm, Toggle
124269	Link
124279	Link, Feed Punch
124284	Arm, Toggle
124313	Magnet Assembly (25 MA at 120 V.DC)
124320	Armature
124355	Insulator
125011	Washer, Flat
125015	Washer, Flat
142835	Shaft, Toggle Arm
142846	Bracket, Link Pivot
142847	Shaft, Link
142848	Clamp, Link Pivot Bracket
142849	Wick, Felt
142850	Clamp
142852	Bracket, Arm Stop
142853 142855	Stud, Arm Stop Bracket
142856	Bracket, Spring (Left) Bracket, Spring (Right)
142857	Spring
142866	Magnet Assembly (1A at 28 V.DC)
142867	Yoke
142869	Screw, Adjusting (4-40)
142871	Armature
142872	Armature
142946	Pawl
142949	Pawl
142992	Plate W/Post
142994	Bar, Magnet Mounting (RT)
142995	Bar, Magnet Mounting (RB)
142996	Bar, Magnet Mounting (LT)
142997	Bar, Magnet Mounting (LB)
142998	Screw, Special (6-40)
143050	Plate, Stop
151631	Screw (6-40 x 5/16 Hex)
151637	Screw (4-40 x 1/4 Fil)
151658 153442	Screw (6-40 x 5/16 Fil) Screw (10-32 x 1/2 Hex)
156632	Screw (10-32 x 1/2 nex) Screw (6-40 x 13/32 Hex)
150052	3010W (0 40 X 10/ 02 116X)

CHANGE


		HOMENICAL IIIDL	X 1 10 01	
Part			Part-	
Number	Description	1	Number	Description
2191	Washer, Lock	•	143040	Ring, Retaining
2539	Nut (3/8 - 32 Hex)	•	151606	Screw (10-32 $\times$ 1/4 Hex)
2669	Washer, Lock	v '	151630	Screw $(6-40 \times 1/4 \text{ Hex})$
3598	Nut (6-40 Hex)		151658	Screw (6-40 x 5/16 Fil)
3606	Nut (6-40 Hex)		151687	Screw (4-40 x 7/16 Fil)
3639	Washer, Lock		151694	Screw (6-40 x 11/32 Fil)
3640	Washer, Lock		151722	Screw (6-40 x 3/16 Hex)
5740	Screw (2-56 x 1/4 Fil)	•	156536	Screw (4-40 x 1/8 Fil)
7002	Washer, Flat	,	170760	Plates, Guide & Die Set
8330	Washer, Flat	,	170766	Spacer
42823	Washer, Flat			
70891	Washer, Lock			
71073	Washer, Flat			
74036	Nut (10-32 Hex)			
74807	Nut (10-32 Hex)			
89896	Oiler			
90437	Wick, Oil			
93118	Washer, Lock			
101892	Dowel			
112626	Nut (10-32 Hex)			
119652	Ring, Retaining			
124231	Nut (10-32 Hex)			
124331	Punch, Feed			
124332	Punch, Code			
125138 125421	Screw (2–56 x 3/8 Fil) Dowel			
125683	Bushing, Eccentric			
125948	Screw (2-55 x 1/8 Fil)			
128357	Ring, Retaining			
142858	Block Assembly, Punch			
142859	Block, Punch			
142860	Plate, Guide		,	
142861	Plates, Guide & Die Set			
142864	Backstop			
<b>∠142865</b>	Screw $(6-40 \times 2-1/32 \text{ Hex})$			
142873	Arm, Detent			
142876	Spring			
142888	Wheel, Feed			
142889	Post, Tape Lid			
142890	Lid, W/Arm Tape			
142893	Block, Pawl			
142895	Spring			
142896	Shaft, Feed Wheel			
142897	Spring			
142901	Plate			
142910	Stud Detent Support			
142911	Plate, Connecting			
142912	Bushing, Eccentric			
142916	Guide, Tape			
142917	Cutter, Tape			
142918	Chut, Chad			
142921	Stud			
142924	Roller			
142942	Bracket, Tape Guide			
143026 143027	Eccentric Guide			
14302/	Golde			




Page Number	Description
	Washer, Lock Nut, (3/8-32 Hex) Washer, Lock Nut (4-40 Hex) Washer, Lock Washer, Flat Washer, Flat Washer, Flat Washer, Elat Washer, Flat Washer, Flat Washer, Flat Washer, Flat Washer, Flat Washer, Flat Washer, Flock Bearing, Ball Spacer Disk Flywheel W/Block Washer, Spring Housing, Bearing Screw (10-32 x 3/16 Set) Spacer Shield, Feed Bearing Bearing Link, Feed Bearing Clamp Shield, Feed Bearing Arm, Bearing Spacer Bearing
142838	Spacer Bearing
142840 142841 142842	Clamp, Bearing Counterweight Key
142844 142845 142880 142882 142887 151073 151630 151633 151637 151660	Spacer, Bearing Arm Clip, Bearing Plate, Front Clamp, Bearing Retainer Screw (4-40 x 5/32 Fil) Screw (6-40 x 1/4 Hex) Bearing Ball Screw (4-40 x 1/4 Fil) Screw (6-40 x 7/8 Fil)
151880 152426 171692	Nut (4–40 Hex) Nut, Self Locking Shaft




\*NOT PART OF 142925



Part Number	Description
2191	Washer, Lock
80957	Screw $(4-40 \times 1/4 \text{ Hex})$
93969	Screw $(4-40 \times 3/16 \text{ Flat})$
110743	Washer, Lock
119662	Screw $(6-40 \times 5/32 \text{ Hex})$
125171	Screw (10-32 $\times$ 1/2 Flat)
142877	Post
142913	Bumper, Rubber
142927	Bar
142928	Bar
142929	Cover, Chad
142932	Stud
142933	Box, Chad



Part Number	Description	
Number  1164 3598 7002 34432 55005C 110435 112627 119652 124292 124293 124294 125015 125112 142889 142988 142988 142988 142989 143007 143041 —143042 143043 150948A 150950 151630 151658 151796 155752 161238 170754 170756	Description  Screw (2–56 x 3/16 Fil) Nut (6–40 Hex) Washer, Flat Washer, Flat Washer, Flat Nut (6–40 Hex) Nut (2–56 Hex) Ring, Retaining Bracket Stud Roller Washer, Flat Screw (2–56 x 1/8 Fil) Post, Tape Lid Guide, Tape Cover W/Window Window Pick-up, Magnetic Screw, Special (4–40) Oiler, Felt Bracket Plate, Identification Plate, Identification Screw (6–40 x 1/4 Hex) Screw (6–40 x 5/16 Fil) Plate, Identification Sleeve, Insulating Connector, Receptacle (36 Pt.) Bracket, Tape Guide Mtg. Bracket, Tape Guide	Sund feed pin 124331  Sund Code pin 124332  Suide Glate 142860  Stud Setat support 142910  Tragnet assembly, 28 142866  Belt 135097  Die Block & Channel 143056-1  Backstop 142864  Clater, guide 3 142861  and die set 3 142861  Curch block assembly  Punit code with in 143056-1  line feed hole
		20,




\*\* SEE COLOR CODE CHART ON PAGE C


FIGURE 1-10. MOTOR COVER (BRPEC)


Part Number	Description
142991**	Cover
154399	Plate, Identification (Bell)
156770	Plate, Identification (Teletype)
156993	Nut, Speed
156993	Nut, Speed

# **SECTION 2**


TAPE PUNCHES (BRPEI, 2, 3 AND 5)











MAGNET MOUNTING PLATE ASSEMBLY

















FEED WHEEL & TAPE GUIDE ASSEMBLY







TAPE FEED-OUT MECHANISM


A,B AND C SEE PAGE 4-2 FOR EXPLANATION






A SEE PAGE 4-2 FOR EXPLANATION







WINDOW COVER ASSEMBLY



136127\*\* MODIFICATION KIT TO EQUIP A HIGH SPEED TAPE PUNCH WITH A MOTOR COVER



#### MAIN SHAFT PARTS



**REAR PLATE PARTS** 

139956 MODIFICATION KIT TO ADD A MAGNETIC PICK-UP

<sup>\*</sup>NOT PART OF 139956 MODIFICATION KIT

<sup>\*\*</sup>FOR UNITS NOT HAVING MANUAL TAPE FEED OUT

# SECTION 3

MOTOR UNIT




FIGURE 3-1. LMU3 AND LMU15 SYNCHRONOUS MOTOR UNITS

Part	
Number	Description
2191	Washer, Lock
2263	Nut (8-32 Hex)
3640	Washer, Lock
7002	Washer, Flat
71999	Spring, Motor Thrust
87334	Washer, Insulating
96264R	Strap, Terminal (5")
122201	Bearing, Ball
122211	Washer, Pull
122220	Oiler, Ball
122229	Bolt, Clamping
122245	Capacitor (43–48 MFD)
122249	Switch, Thermostatic
122251	Stator, Motor
122252	Shield Assembly, End
123769	Fan, Motor
125011	Washer, Flat
128874	Rotor, Motor
150040	Screw (6-40 × 5/8 Fil)
150976	Bracket, Motor Mounting
151346	Screw (6-40 $\times$ 3/8 Fil)
151620	Strap, Motor Mounting
151621	Screw $(6-32 \times 3/4 \text{ Rd})$
151622	Nut (6-32 Sq)
151626	Terminal
151637	Screw $(4-40 \times 1/4 \text{ Fil})$
151686	Screw (4-40 x 3/8 Fil)
151692	Screw (6-40 x 3/16 Fil)
151795	Motor, Synchronous - 1/12 H.P.
	115/1/60 Cycle, AC General Electric
	Model 5SC19LG10 - with fan
151920	Plate, Mounting
151922	Clamp
151923	Relay
151924	Plate, Insulating
151925	Clamp
151926	Nut (4-40 Spl)
151927	Cable, Motor Unit
152297	Washer, Bearing
153030	Mount, Vibration
153049	Washer, Fiber Motor, Synchronous – 1/12 H.P.
170764	Motor, Synchronous - 1/12 H.P.
	115/1/60 Cycle, AC General Electric
	Model 5SC19LG10 - without fan

CHANGE 5




FIGURE 3-2. 113779 AND 135080 SET OF MOTOR MOUNTING AND DRIVE PARTS (600 0.P.M. - GEAR DRIVE)




FIGURE 3-3. 135259 SET OF MOTOR MOUNTING AND DRIVE PARTS (3600 O.P.M. - DIRECT DRIVE)

# NUMBERICAL INDEX FIGURES 3-2, 3-3

Part Number	Description
1036	Nut (6-40 Hex)
1179	Screw (6-40 x 5/8 Fil)
1248	Screw (6-40 $\times$ 1/2 Flat)
1269	Screw (6-40 x 1/2 Fil)
2191	Washer, Lock
2449	Washer, Lock
2669	Washer, Lock
3438	Washer, Flat
6745	Screw (10-32 $\times$ 1/2 He $\times$ )
7002	Washer, Flat
74807	Nut (10-32 Hex)
104124	Screw $(1/4-32 \times 11/32 \text{ Hex})$
108103	Washer, Flat
124390	Stud
124391	Plate, Motor Mounting
124392	Coupling, Flexible
135075	Post
135076	Gear (84T)
135077	Hub, Gear
135671	Gear (14T)
135784	Guard, Gear





FIGURE 3-4. 113762 MODIFICATION KIT TO PROVIDE MOTOR MOUNTING AND DRIVE PARTS (3800.0.P. M BELT DRIVE)

1 th 1 - 1	
Page	
Number	Description
2191	Washer, Lock
2669	Washer, Lock
3438	Washer, Flat
85422	Screw (10-32 x 15/16 Hex)
135093	Spacer
135094	Sprocket
135095	Retainer, Belt
135096	Hub
135097	Belt
135178	Sprocket
135179	Hub
151693	Screw (6-40 x 9/16 Fil)
151721	Screw (6-40 x 3/4 Hex)



SPECIFICATION 5944S

FIGURE 3-5. 143044 MODIFICATION KIT TO PROVIDE MOTOR MOUNTING AND DRIVE PARTS (110 characters-per-second)

Part Number	Description
2191	Washer, Lock
3606	Nut (6-40 Hex)
3639	Washer, Lock
85422	Screw (10-32 x 15/16 Hex)
90511	Screw (6-40 x 13/16 Hex)
94072	Spacer
102392	Spacer
102664	Hub
125733	Washer, Flat
143052	Sprocket (24 Grooves)
143053	Hub
143054	Sprocket (44 Grooves)
143055	Belt (13" Pitch Length)
151724	Screw (10-32 x 5/8 Hex.)
171190	Sprocket (44 Grooves)





FIGURE 3-6. 143062 MODIFICATION KIT TO PROVIDE MOTOR MOUNTING AND DRIVE PARTS (3800 O.P.M. BELT DRIVE)

Part Number	Description
Homber	D0301.1p1.101.
2191	Washer, Lock
2669	Washer, Lock
3438	Washer, Flat
81596	Screw (10-32 $\times$ 1-3/8 Hex)
125733	Washer, Flat
151346	Screw (6-40 $\times$ .375 Fil)
151721	Screw (6-40 x 3/4 Hex)
135094	Sprocket
135095	Retainer, Belt
135097	Belt
143038	Spacer
143039	Hub
143053	Hub
143061	Sprocket, Driven

Part Number	Description
Number  2191 6345 7002 71999 91837 92260 98642 111062 122200 122201 122202 122204 122205 122206 122208 122210	Description  Washer, Lock Nut (6-32 Hex) Washer, Flat Spring, Motor Thrust Washer, Fiber Washer, Lock Washer, Lock Terminal Shield Assembly, End Bearing, Ball Bolt, Clamping (10-32) Cap, Brush Brush w/Spring Holder, Brush Washer, Flat Armature Washer, Pull Oiler, Ball Stator Capacitor Assembly Shield Assembly, End Screw (6-32 x 5/16 Flat) Motor, Series Collar, Spacing Spring, Governor Brush Spring, Governor Brush Brush Mounting, Brush Plate, Brush Plate, Brush Plate, Clamp Screw (6-40 x 3/8 Fil ) Nut (10-32 Hex) Spring, Helical Clip Strap, Motor Mounting Screw (6-40 x 3/4 Fil ) Screw (6-40 x 1/4 Hex) Screw (6-40 x 1/4 Fil ) Screw (6-40 x 1 Fil ) Mount, Vibration
153031 153101 153102 153103 153114	Bushing, Lead Grommet Screw, Set (8–32) Screw, Self Tapping Wire Assembly



\*\*PART OF 122253 ##PART OF 122233

FIGURE 3-7. SERIES MOTOR FOR LMU6 MOTOR UNIT

FIGURE 3-8.

150845 GOVERNOR ASSEMBLY FOR LMU6 MOTOR UNIT

Part	
Number	Description
2101	W 1 1 1
2191	Washer, Lock
6320	Screw, Contact
6345	Nut (6-32 Hex)
7002	Washer, Flat
98712	Screw (4–40 x 7/32 Flat)
110743	Washer, Lock
125011	Washer, Flat
150849	Washer, Insulating
150850	Plate, Insulating
150856	Arm, Movable Contact
150857	Clamp, Contact Arm
150858	Bracket, Contact
150859	Bracket, Contact Arm Mounting
150865	Screw, Clamping (4–40)
150866	Clamp, Adjusting Screw Locking
150868	Bushing, Insulating
150869	Spring, Governor
150872	Stud, Cover Mounting
150877	Bracket, Governor Spring Guide
150879	Cover, Governor
150997	Fan, Governor
151152	Screw (4-40 x 3/16 Hex)
151637	Screw (4-40 x 1/4 Fil)
151659	Screw (6-40 x 1/2 Fil)
151661	Screw (6-40 x 1 Fil)
152495	Bushing
154375	Backstop
•	




FIGURE 3-9. MOUNTING PARTS FOR LMU6 MOTOR UNIT

Part	
Number	Description
2191	Washer, Lock
3598	Nut (6-40 Hex)
3624	Washer, Flat
5740	Screw $(2-56 \times 1/4 \text{ Fil})$
8449	Collar
61085	Washer, Lock
73374	Spacer
91837	Washer, Fiber
100743	Clamp, Cable
112627	Nut (2-56 Hex)
150976	Bracket, Motor Mounting
150980	Plate, Clamping
150995	Bushing, Insulating
151631	Screw (6-40 $\times$ 5/16 Hex)
151661	Screw (6-40 x 1 Fil )
152459	Bracket, Resistor Mounting
161579	Capacitor (1/2 MF)
161580	Resistor (500 ohm)
162861	Screw (6-40 x 1-7/16 Fil )
163267	Wire w/Terminal (2-3/4" lg)
163268	Wire w/Terminal (6-1/2" lg)
163269	Wire w/Terminals (2" lg)
164479	Terminal

# **SECTION 4**

MISCELLANEOUS REFERENCE

#### NCTES OF EXPLANATION

#### PAGE 2-2

(A) The 151661 screw (1" long) replaces the 151346 screw (3/8" long) when the 108162 spacer is used.

#### PAGE 2-6

- (A) The 72508 screws (6-40 x 3/4" Hex) replaces the 129763 screws (6-40 x 11/16" Fil) on units with only 1 timing contactor.
- (B) The 135666 bushing replaces the bearing and clamp on units with only 1 timing contactor.
- (C) The 124269 link is used with all code punches and the in-line feed punch. The 135176 link is used with the advanced feed punch.

#### PAGE 2-7

(A) The 135667 spacer replaces the 129760 plate on units with only 1 timing contactor.

#### PAGE 3-4

(A) The 135784 gear guard is not included with the 135080 modification kit. The 135079 tape guide bracket shown on Page 2-2 is part of the 135080 modification kit.

#### MODIFICATION KITS

(The parts involved are shown on the pages indicated below)

136010 and 136011 Modification Kits to provide tape-out alarm.

Part			Page
Number	Description	Quantity	Number
1178	Screw (2-56 x 7/16 Fil)	2	2-2
93118	Washer, Lock	2	2-2
139770	Spring	1	2-2
*124377	Plate, Left Side	1	2-2
151329	Switch	1	2-2
151233	Washer, Flat	2	2-2
135668	Spacer	1	2-2
135670	Lever	1	2-2

<sup>\*</sup> Peculiar to 136010 (order if plate on unit has no switch mounting holes).

(Specification 5808S).

136016 Modification Kit to adapt a 6 or 7 unit BRPE for two tape perforation. 136017 Modification Kit to adapt a 5 unit BRPE for two tape perforation.

Part			Page
Number	Description	Quantity	Number
2191	Washer, Lock	4	
3598	Nut (6-40 Hex)	i ·	
3606	Nut (6-40 Hex)	1	
76299	Spring	1 .	2-2
119649	Ring, Retaining	2	2-2
119652	Ring, Retaining	1 .	2-8
124291	Guide	1	2-8
124293	Stud	1	2-8
124294	Roller	1	2-8
124341	Brake	1	2-2
124342	Shaft	1	2-2
124356	Guard	1	2-8
124357	Bracket	1	2-8
124375	Plate	2	2-2
124376	Spacer	2	2-2
124380	Guide	1	2-2
124381	Stud	1	2-2
124382	Washer, Flat	1	2-2
124383	Reel Assembly	. 1	2-2
*124388	Retainer Assembly	1	2-2
125015	Washer, Flat	2	
**135086	Retainer Assembly	1	2-2
136466	Spacer	2	
136467	Screw (10-32 x 3-1/4 Fil)	2	
151630	Screw $(6-40 \times 1/4 \text{ Hex})$	2	
151631	Screw $(6-40 \times 5/16 \text{ Hex})$	2	
	· · · · · · · · · · · · · · · · · · ·		

<sup>\*</sup> Peculiar to 136016.

<sup>(</sup>Specification 5818S)

<sup>\*\*</sup> Peculiar to 136017.

<sup>(</sup>Specification 5818S)

# **SECTION 5**

**NUMERICAL INDEX** 

#### NUMERICAL INDEX

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
1030	Scrow Shoulder // 40\ 2 0 0 0	7/0//	6	110710	
1036	Screw, Shoulder (6-40) 2-2,2-3 Nut (6-40 Hex) 1-2,2-2,3-4	76966 76804	Screw. Set (10-32) 2-10 Spring 2-6	112769 114466	Washer, Flat 2-3
1159	Screw (4-40 × 3/8 Fil) 1-10	76983	Screw (4-40 × 1-1/4 Fil) 1-14	114467	Connector 1-2 Connector 1-2
1164	Screw (2-56 x 3/16 Fil) 1-10.1-18.	78469	Foot 2-9	114589	Mount, Vibration 1-2
11-1	2-6	80845	Screw (10-32 x 1-13/16 Fil) 1-4	115221	Washer, Felt 1–8
1174 1178	Screw, Shoulder (4-40) 2-9	80957	Screw (4-40 x 1-1/4 Hex) 1-16	118576	Clamp, Cable 2-7
1178	Screw (2-56 x 7/16 Fil) 2-2 Screw (6-40 x 5/8 Fil) 3-4	81596	Screw (10-32 x 1-3/8 Hex) 3-6, 3-10	118577	Clamp, Cable 2-2
1215	Screw. Shoulder (6-40) 2-3	82097	Spring. Contact 1–6	119337 119648	Plate, Name 1–2, 2–2 Ring, Retaining 1–8
1248	Screw (6-40 x 5/8 Fil) 3-4	82474	Terminal 2-2	119649	Ring, Retaining 1-4, 2-2
1269	Screw (6-40 x 1/2 Fil) 3-4	82547	Insulator 1–6	119651	Ring, Retaining 1-10, 2-5
1293 2191	Screw (4-40 x 1/8 Fil) 2-6	82548	Insulator 1-6	119652	Ring, Retaining 1-8, 1-12, 1-18,
2171	Washer, Lock 1-2,1-4,1-6,1-8, 1-10,1-12,1-14,1-16,1-18,2-2,	82726 82747	Spring 1-10	110//0	2-5, 2-8
	2-3, 2-4, 2-5, 2-6, 2-7, 2-8, 2-9,	84666	Terminal 1-2 Sprina. Contact 1-6	119662 121244	Screw (6-40 x 5/32 Hex) 1-16 Clamp, Cable 1-2
	2-10, 3-2, 3-4, 3-6, 3-8, 3, 10, 3-12,	84705	Spring, Contact 1-6	121246	Clamp, Cable 2-2
0010	3-14,3-16	85020	Screw, Shoulder (10-32) 1-2	121248	Clamp, Cable 2-2
2263 2449	Nut (8-32 Hex) 3-2	85422	Screw (10-32 x 5/16 Hex) 3-6.3-8	122200	Shield Assembly 3-12
2539	Washer, Lock 1-2.3-4 Nut (3/8-32) Hex) 1-12, 1-14, 2-6,	86774 87334	Screw, Shoulder (6-40) 1-8	122201	Bearing, Ball 3-2,3-12
2337	2-10	89896.	Washer. Insulating 3–2 Oiler 1–12.2–5	122202 122204	Bolt, Clamping (10–32) 3–12 Cap, Brush 3–12
2669	Washer, Lock 1-2.1-4,1-8,1-10	90361	Washer, Felt 1–8	122205	Brush w/Spring 3-12
	1-12.1-14.2-2.2-5.2-6.3-4.3-6,	90436	Wick, Felt 2-5	122206	Holder, Brush 3-12
2.420	3-10	90437	Wick, Oil 1-12, 2-5	122208	Washer, Flat 3-12
3438 <b>3624</b>	Washer, Flat 2-2.3-4.3-6.3-10 Washer, Flat 3-16	90511 90791	Screw (6-40 x 13/16 Hex) 3-8	122210	Armature 3-12
3598	Nut (6-40 Hex) 1-8.1-10,1-12,	91683	Washer, Lock 2–7 Nut (15/32–32 Hex) 1–2, 2–2	122211 122220	Washer, Pull 3-2,3-12 Oiler, Ball 3-2,3-12
	1-18, 2-3, 2-5, 2-8, 2-10, 3-16	91684	Nut (15/32-32 Ring) 1-2, 2-2	122221	Stator 3-12
3599	Nut (6-40 Hex) 1-8.1-10.1-14.	91837	Washer, Fiber 3-12,3-16	122233	Capacitor Assembly 3-12
0/0/	2-5.2-6.2-7	92128	Bearing, Ball 2-6, 2-10	122245	Capacitor 3-2
3606	Nut (6-40 Hex) 1-4, 1-8, 2-2, 2-3,	92260 93107	Washer, Lock 3-12	122249	Switch 3-2
3624	2-6, 2-9, 3-8 Washer, Flat 2-7	93117	Bearing, Ball 2–6 Washer, Lock 1–10, 2–6	122251 122252	Stator 3–2 Shield Assembly 3–2
3639	Washer, Lock 1-12.2-5.3-8	93118	Washer, Lock 1-12, 2-2	122253	Shield Assembly 3-12
3640	Washer, Lock 1-6.1-8.1-10.1-12.	93582	Washer, Flat 2-6	123769	Fan 3-2
	1-14, 2-3, 2-5, 2-6, 2-7, 3-2	93969	Screw (4-40 x 3/16 Flat) 1-16	124224	Plate 2-3, 2-10
4703	Spring 2-3	93985	Washer, Lock 1-2	124225	Housing 2-6, 2-10
5740	Screw $(2-56 \times 1/4 \text{ Fil})1-12$ , 2-4, 3-16	94072 95320	Spacer 3–8 Switch 1–2, 2–2	124226 124227	Retainer 2–6 Stud 2–5
6320	Screw, Contact 3-14	96264R	Strap 3-2	124229	Wheel 2-5
6345	Nut (6-32 Hex) 3-12,3-14	97266	Plate, Clamp 1-6	124230	Guide 2-5
6745	Screw (10-32 x 1/2 Hex) 1-4.3-4	98436	Spacer 2-9	124231	Nut (10-32 Hex) 1-2, 2-5
6746 7002	(6-40 x 5/16 Hex) 2-2	98642 98712	Washer, Lock 3–12 Screw (4–40 x 7/32 Flat) 3–14	124232	Stud 2-3
7002	Washer, Flat 1-2.1-4.1-8.1-10. 1-12.1-14.1-18.2-2.2-7.2-10.	98726	Screw (3-48 x 1/4 Fil) 1-2	124233 124234	Stud 2-5 Lever 2-5
	3-2, 3-4,3-12,3-14	100516	Screw (10-32 x 1-1/4 Hex) 2-2	124235	Support
8330	Washer, Flat 1-12, 2-3, 2-4, 2-5.	100743	Clamp, Cable 3-16	124236	Arm 2-6
8449	2-9 Collar 3-16	101115	Eccentric 2-3	124243	Bracket 2-3
34432		101633	Washer, Flat 1-14	124244	Washer, Felt 1-10, 2-5
34432	Washer, Flat 1-8.1-18.2-2.2-5. 2-8	101862 101892	Spacer 2–2 Dowel 1–12, 2–4	124245 124246	Pawl 2-3 Pawl 2-3
35503	Foot, Rubber 2-2	102392	Spacer 3-8	124247	Stud 2-3
36463	Spring 1-8	102664	Hub 3-8	124248	Plate 2-3
41382	Spring 2-6	103539	Screw (6-40 x 3/8 Fil) 2-9	124249	Spacer 1-8, 2-3
41675 42823	Washer, Flat 1-8.2-5 Washer, Flat 1-10,1-12,1-14	104124 104705	Screw (1/4-32 x 11/32 Hex) 3-4 Bearing, Ball 2-6	124250 124251	Stud 2-3
45104	Spring 2-6	104807	Washer, Flat	124251	Stud 2-5 Link 1-8, 2-5
49056	Screw (10-32 x 7/8 Hex) 2-2	104824	Spring 2-3	124254	Shaft 2-6, 2-10
55005C	Washer. Flat 1-18	108103	Washer, Flat 3–4	124255	Link 2-6
61085	Washer, Lock 3–16	110434	Screw (4-40 x 3/16 Fil) 1-10, 2-2,	124256	Clamp 2-6
70072	Washer, Flat 1-2	110435	2-5 Nut (4-40 Hex) 1-8, 1-10, 1-18,	124257	Arm 1-10, 2-5
70891 71073	Washer, Lock 1-12 Washer, Flat 1-12	110433	2-6, 2-8, 2-9	124258 124259	Screw, Shoulder (4-40) 1-8, 2-5 Stud 2-5
71999	Spring 3-2,3-12	110743	Washer, Lock 1-8, 1-10, 1-14,	124260	Pawl 2-6
72508	Screw (6-40 $\times$ 1/4 Hex) 2-6		1-16, 2-2, 2-7, 2-8, 2-9, 3-14	124266	Link 2-6
73175 73374	Washer, Lock 1-14,2-6,2-10	110974	Spring 2-5	124268	Bracket 2-6
	Spacer 3-16	111017	Screw (6-40 x 5/16 Rd) 1-2, 1-8, 2-2	124269	Link 1-10, 2-6
74036	Nut (10-32 Hex) 1-4, 1-8, 1-12, 1-14, 2-2, 2-5, 2-6	111062	Z-Z Terminal 3-12	124270 124271	Shaft 2–6 Clamp 2–6
74554	Post 2-3	111345	Bolt 2-9	124272	Spacer 2-6
74712	Spring 1-4	111346	Spring 2-9	124273	Arm 2-6
74728	Terminal 1-6	111347	Screw, Thumb 2-9	124274	Clamp 2-6
74805	Screw (10-32 x 3/4 Hex) 1-2,2-2	111410 112100	Washer, Flat 1–10 Bushing 1–6	124275 124276	Spacer 2-6
74807 76099	Nut (10-32 Hex) 1-12,3-4 Washer, Flat 2-10	112626	Nut (10-32 Hex) 1-8, 1-12, 2-5	124276	Screw (4-40 x 1-3/64 Fil) 2-6 Bail 2-5, 2-6
76299	Spring 2-2	112627	Nut (2-56 Hex) 1-18,3-16	124279	Link 1-10, 2-5

#### NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
124280	Shaft 2-5	124380	Guide 2-2	139958	Disk 1-14, 2-10
124281	Spacer 2-6	124381	Stud 2-2	139959	Scale 2-10
124282	Spacer 1-8, 2-3		Washer, Flat 1-4, 2-2	139960	Spacer 2-10
124283 124284	Spacer 2-3 Arm 1-10, 2-6	124383 124388	Reel 2-2 Retainer 2-2	139961 139962	Pickup, Magnetic 2-10 Flywheel w/Block 1-14, 2-10
124285	Post 2-6	124390	Stud 3-4	139989	Post 2-10
124286	Post 2-6	124391	Plate 3-4	139990	Post 2-10
124287	Spacer 1-8, 2-5	124392	Coupling 3-4	139991	Post 1-8, 2-10
124288	Post 2-3	124395	Connector 2-2	139992	Button 1-14, 2-10
124289	Bearing, Ball 1-14, 2-6	124396 124408	Switch Assembly 1-2, 2-2	139997 142743	Washer, Spring 1-14, 2-10 Shim (.004") 2-3
124290 124291	Clamp 2-6 Stud 1-12, 2-8		Bracket Assembly 2-8 Washer, Flat 1-6, 1-10, 2-2, 2-3.	142800	Plate 1-8
124292	Bracket 1-18, 2-8		2-5, 2-7, 2-8, 2-9, 3-2,3-14	142801	Housing 1-14
124293	Stud 1-18, 2-8		Washer, Flat 1-10, 1-18, 2-2, 2-8	142802	Shaft 1-14
124294	Roller 1-12, 1-18, 2-8		Screw (2-56 x 1/8 Fil) 1-18	142803	Screw, Set (10-32) 1-14
124296	Roller 2-5	125126	Screw (2-56 x 9/32 Fil) 2-7	142806	Shield 1-14
124300 124301	Spacer 1-8, 2-3 Spacer 1-14, 2-6	125138 125143	Screw (2-56 x 3/8 Fil) 1-12. 2-4 Screw (6-32 x 5/16 Flat) 3-12	142807 142808	Bearing 1-14 Shield 1-14
124302	Pin 2-7	125171	Screw (10-32 x 1/2 Flat) 1-16	142809	Clamp 1-14
124303	Bushing 2-7, 2-10	125218	Nut (1/4-32 Hex) 1-2	142810	Shield 1-14
124305	Plate 2-7	125421	Dowel 1-12, 2-4	142811	Stud 1-8
124306	Arm 2-6	125683	Bushing 1-12, 2-5	142812	Stud 1-8
124308 124310	Eccentric 2-6 Clamp 2-6	125733 125948	Washer, Flat 3-8, 3-10 Screw (2-56 x 1/8 Fil) 1-12	142828 142829	Pawl 1-8 Pin 1-8
124311	Plate 2-3	128357	Ring, Retaining 1-12	142833	Arm 1-14
124312	Yoke 2-3	128874	Rotor 3-2	142834	Bail 1-8
124313	Magnet Assembly 1-10, 2-3	129755	Spring 2-2	142835	Shaft 1-10
124318	Washer, Insulating 2–3	129758	Bracket 2-2	142838	Spacer 1-14
124319 124320	Post 2-3 Armature 1-10, 2-3	129760	Plate 2-7 Plate 2-7	142839 142840	Bearing 1-14 Clamp 1-14
124321	Bracket 2-3	129761 129762	Plate 2-8	142841	Counterweight 1-14
124322	Plate 2-3	129763	Screw (6-40 x 11/16 Fil) 2-6, 2-10	142842	Key 1-14
124323	Plate 2-3	129764	Nut, Special 2-7	142844	Spacer 1–14
124324	Plate 2-3	129765	Shim (.020") 2-6	142845	Clip 1-14
124325 124326	Block Assembly 2-4 Block 2-4	129766	Stud 2-3	142846 142847	Bracket 1-10
124327	Plate 2-4	1 <i>2</i> 9768 1 <b>29769</b>	Lever 2-3, 2-10 Window 2-8	142848	Shaft 1-10 Clamp 1-10
124328	Plates 2-4	129770	Cover 2-8	142849	Wick, Felt 1-10
124331	Punch 1-12, 2-4	129771	Screw, Thumb 2-7	142850	Clamp 1-10
124332	Punch 1-12, 2-4	131098	Terminal 1-2	142852	Bracket 1-10
124333 124334	Backstop 2-4	135075	Post 3-4	142853 142855	Stud 1-10 Bracket 1-10
124334	Screw (6-40 x 1-27/32 Hex) 2-4 Chute 2-3	135076 135077	Gear (84T) 3-4 Hub 3-4	142856	Bracket 1-10
124336	Block Assembly 2-4	135079	Bracket 2-2	142857	Spring 1-10
124338	Plates 2-4	135086	Retainer, Tape 1-4, 2-2	142858	Block Assembly 1-12
124341	Brake 2-2	135094	Sprocket 3-6, 3-10	142859	Block 1-12
124342	Shaft 2-2	135095	Retainer 3-6, 3-10	142860 142861	Plate 1-12 Plate 1-12
124343 124344	Spacer 2–5 Stud 2–4	135096 135097	Hub 3-6 Belt 3-6, 3-10	142864	Stop 1-12
124349	Connector 2-7	135175	Wheel 2-5	142865	Screw (6-40 x 2-1/32 Hex) 1-12
124350	Connector 2-7	135176	Link 2-6	142866	Magnet Assembly 1-10
124351	Post 2-6	135177	Block Assembly 2-4	142867	Yoke 1-10
124353	Plate 2-4 Box 2-7	135178	Sprocket 3-6	14 <b>28</b> 69 142871	Screw, Adjusting (4-40) 1-10 Armature 1-10
124354 124355	Insulator 1-10, 2-3	135179 135180	Hub 3-6 Block 2-4	142872	Armature 1-10
124356	Guard, Tape 2-8	135181	Plate 2-4	142873	Arm, Detent 1-12
124357	Bracket 2-8	135182	Plates 2-4	142876	Spring 1-12
124358	Bearing, Ball 2-6	135183	Backstop 2-4	142877	Post 1-16
124360	Bar 2-2	135247	Oiler, Felt 1-8, 2-5 Strap 2-2	142880 142882	Plate, Front 1-14 Clamp 1-14
124361 124362	Bar 2-2 Plate 2-2	135563 135568	Spacer 2	142887	Retainer 1-14
124363	Bar 2-2	135666	Bushing 2-6	142888	Wheel 1-12
124364	Bracket 2-2	135667	Spacer 2-7	142889	Post 1-12, 1-18
124365	Bracket 2-2	135669	Post 2-2	142890	Lid 1-12
124366	Strip 2-2	135670	Lever 1-4, 2-2	142893 142895	Block 1-12 Spring 1-12
124367 124368	Strip 2–2 Plate 2–2	135671 135673	Gear (14T) 3-4 Cover 2-8	142895	Shaft 1-12
124369	Strip 2-2	135784	Guard 3-4	142897	Spring 1-12
124370	Plate 2-2	136127**	Modification Kit 2-9	142898	Connector 1-2, 1-18
124371	Stud 2-2	139500	Window 2-9	142899	Connector 1-2
124372	Box 2-2	139501	Arm 2-9	142901	Plate 1-12 Stud 1-12
124373	Bracket 2-2	139502	Plate 2-9 Cover w/Brackets 2-9	142910 142911	Plate 1-12
124374 124375	Bushing 2–2 Plate, Front 2–2, 1–4	139563**		142912	Bushing 1-12
124376	Spacer 2-2	139770	Spring 1-4, 2-2	142913	Bumper, Rubber 1-16
124377	Plate 2-2	139957	Bracket 1-14, 2-10	142915	Bracket, Mountina 1–2

#### NUMERICAL INDEX (Continued)

Part Number	Description and Page Number	Part Number	Description and Page Number	Part Number	Description and Page Number
		1.00.50	PL - 1.10	151442	Screw (6-40 x 3/4 Fil) 3-12
142916	Guide 1-12	143050	Plate 1-10	151642 151657	(6-40 x 1/4 Fil) 1-2, 2-2, 2-3, 2-5
142917	Cutter 1-12	143052 143053	Sprocket 3-8 Hub 3-8, 3-10	151658	Screw (6-40 x 5/16 Fil) 1-10, 1-12
142918	Chute 1-12	143053	Sprocket 3-8	131030	1-18, 2-7, 2-8, 3-12
142921 <b>143</b> 923	Stud 1-12 Post 1-8	143055	Belt 3-8	151659	Screw (6-40 x 1/2 Fil) 3-14
142924	Roller 1-12	143061	Sprocket, Driven	151660	Screw (6-40 x 7/8 Fil) 1-14. 2-10
142927	Bar 1-16	150040	Screw (6-40 x5/8" Fil.) 3-2	151661	Screw (6-40 x 1 Fil) 2-2, 3-12, 3-14,
142928	Bar 1-16	150411	Washer, Flat 2-7		3-16
142929	Cover 1-16	150701	Motor 3-12	151685	Screw (4-40 × 5/16 Fil) 2-7
142932	Stud 1-16	150845	Governor Assembly 3-14	151686	Screw (4-40 x 3/8 Fil) 2-6, 3-2
142933	Box 1-16	150849 150850	Washer, Insulating 3–14 Plate, Insulating 3–14	151687	Screw (4-40 x 7/16 Fil) 1-12
142939	Cable Assembly 1-2	150856	Arm 3-14	151690 151692	Screw (10-32 x 5/16 Fil) 2-2
142942	Bracket, Tape Guide 1-12	150857	Clamp 3-14	151693	Screw (6-40 x 3/16 Fil) 2-3, 3-2 Screw (6-40 x 9/16 Fil) 2-9, 3-6
142946	Pawl 1-10	150858	Bracket 3-14	151694	Screw (6-40 x 7/10 PH) 2-7, 3-8
142949 142950	Pawl 1-10 Bar, Left 1-2	150859	Bracket 3-14	151721	Screw (6-40 x 3/4 Hex) 3-6, 3-10
142951	Bar, Right 1-2	150865	Screw, Clamping (4-40) 3-14	151722	Screw (6-40 x 3/16 Hex) 1-12
142952	Plate, Mounting 1-2	150866	Clamp 3-14	151723	Screw (10-32 x 3/8 Hex) 1-2, 2-2
142953	Post 1-2	150868	Bushing, Insulating 3-14	151724	Screw (10-32 x 5/8 Hex) 1-2, 1-8,
142954	Stud 1-2	150869	Spring 3-14		2-2, 3-8
142955	Bracket, Left Rear 1-2	150872	Stud 3-14	151731	Screw (4-40 x 7/8 Fil) 2-7
142956	Bracket, Right Rear 1-2	150873	Collar 3-12	151795	Motor 3-2
142959	Plate 1-2	150877	Bracket 3-14	151820	Spring 2-7
142961	Cable Assembly, Base 1-2	150,879	Cover 3-14	151880	Nut (4-40 Hex) 1-6, 1-14
142964	Board, Terminal 1-2	150880	Spring, Brush 3-12	151920	Plate 3-2
142965	Board, Terminal 1-2	150881	Spring, Brush 3-12	151922	Clamp 3-2
142966	Resistor 1-2	150882	Brush 3-12 Mounting, Brush 3-12	151923 151924	Relay 3-2 Plate 3-2
142970	Post 1-2	150884	Plate, Clamp 3-12	151925	Clamp 3-2
142971 142972	Strip, Rear 1-2	150885 150948A	Plate, Identification 1-18	151926	Nut (4-40 Spl) 3-2
142974	Strip, Front 1-2 Roller 1-4	150946A	Plate, Identification 1-18	151927	Cable 3-2
142975	Brake 1–4	150966	Insulator 1-2, 2-2	151927	Washer, Bearing 3-2
142976	Shaft 1-4	150976	Bracket 3-2,3-16	152426	Nut, Self Locking 1-14
142977	Reel, Tape 1-4	150980	Plate, Clamping 3-16	152459	Bracket 3-16
142982	Guide, Tape 1-4	150995	Bushing, Insulating 3-16	152495	Bushing 3-14
142893	Guide 1-18	150997	Fan 3-14	153030	Mount 3-2,3-12
142985	Cable Assembly, Motor 1-2	151073	Screw (4-40 x 5/32 Fil) 1-14, 2-6	153031	Bushing 3-12
142988	Cover w/Window 1-18	151152	Screw (4-40 x 3/16 Hex) 3-14	153049	Washer, Fiber 3–2
142989	Window 1-18	151171	Contact 2-7	153101	Grommet 3-12
142991**		151173	Screw, Contact 2–7	153102 153103	Screw, Set (8-32) 3-12 Screw, Self Tapping 3-12
142992	Plate w/Post 1-10	151176	Base 2-7	153114	Wire Assembly 3-12
142994	Bar 1-10	151177	Terminal 2-7		
142995 142996	Bar 1-10 Bar 1-10	151179	Terminal 2-7	153442 154375	Screw (10–32 x 1/2 Hex) 1–2, 1–10 Backstop 3–14
142997	Bar 1-10	151180 151182	Link 2-7 Washer, Fiber 2-7	154399	Plate, Identification 1-20
142998	Screw (6-40 × 3/8 Flat) 1-10	151183	Insulator 2-7	154661	Rectifier 1-2
143000	Contact Assembly 1-6	151185	Guide 2-7	154697	Grommet, Rubber 1-2
143001	Bracket 1-6	151233	Washer, Flat 2-2	155752	Sleeve, Insulating 1-2, 1-18
143002	Plate 1-4	151329	Switch 2-2	156536	Screw (4-40 x 1/8 Fil) 1-12
143003	Stud 1-6	151335	Stud 2-2	156632	Screw (6-40 x 13/32 Hex) 1-10
143004	Cover, Insulating 1-6	151346	Screw (6-40 x 3/8 Fil) 1-2, 2-2,	156740	Screw (6-40 x $7/32$ Hex) 1-6
143006	Lever w/Post 1-8		2-3, 2-9, 3-2, 3-10	156768	Screw (8-32 x 9/32 Hex) 1-2
143007	Pickup, Magnetic 1-18	151355	Stud (6-40) 1-2	156770	Plate, Identification 1-20
143014	Link w/Hub and Stud 1-8	151359	Cover 2-7	156993	Nut, Speed 1-20
143016	Arm, Toggle 1-8	151415	Block, Terminal 1-2, 2-2	161238	Connector 1-8
143017	Arm 1-8	151453	Nut (10-32 Hex) 3-12	161579 161580	Capacitor 3–16 Resistor 3–16
143019	Spacer 1-8	151455	Spring 3-12	162861	Screw (6-40 x 1-7/16 Fil) 3-16
143020 143021	Spacer 1–8 Plate w/Post and Stud 1–8	151606 151618	Screw (10-32 x 1/4 Hex) 1-12, 2-3 Screw (6-40 x 7/16 Fil) 2-3, 2-6	163267	Wire w/Terminal 3-16
143021	Eccentric 1-8, 1-12	151620	Strap 3-2,3-12	163268	Wire w/Terminal 3-16
143027	Guide 1-12	151621	Screw (6-40 x 3/4 Rd) 3-2,3-12	163269	Wire w/Terminals 3-16
143028	Scale 1-8	151622	Nut (6-32 Sq) 3-2,3-12	164479	Terminal 3-16
143038	Spacer 3-10	151626	Terminal 1-2, 2-2, 3-2, 3-12	170752	Plate, Rear 1-8
143039	Hub 3-10	151630	Screw (6-40 x 1/4 Hex) 1-2, 1-12,	170754	Bracket 1-18
143040	Ring, Retaining 1-12		1-14, 1-18, 2-10,3-12	170756	Bracket 1-8
143041	Screw, Special (4-40) 1-18	151631	Screw (6-40 $\times$ 5/16 Hex) 1-10,	170760	Plates 1-12
143042	Oiler, Felt 1-18		2-2,3-16	170764	Motor 3-2
143043	Bracket 1-18	151632	Screw (6-40 x 1/4 Hex) 2-3	170766	Spacer 1-12
143045	Link w/Bushings 1-8	151633	Bearing, Ball 1-14	171190	Sprocket 3-8
143048	Spring 1- 8	151637	Screw (4-40 x 1/4 Fil) 1-10, 1-14, 2-2, 2-3, 2-7, 2-8, 2-9,3-2,3-14	171692	Shaft